



BTDF – Benefit and use for the characterization of volume diffusors

Workshop on BTDF measurement

2022-04-26, Madrid


Dr. Rafael Oser

Covestro – leading in the world of plastics



Strong

- €15.9 bn in sales
- ~17,900 employees¹



Useful

- Plastics, pre-products and solutions
- For many industries



Global

- 50 production sites globally
- Close to customers and partners



Innovative


- ~1,500 employees in research and development
- 80 years of ideas and inventions



Introduction Polycarbonate

Key Properties of Polycarbonate – Overview


Trade Name:
Makrolon®





Introduction Polycarbonate

T-/R-Spectrum of PC: Makrolon[®] 2808 (3.2mm)



UV-Range:

Visible-Range:

NIR-Range:

UV-Absorber

Color

IR-Absorber

→

→

→

Material protection, UV-Cut (Lens)

Coloring, Tint (Fbl)

Safety Glasses (Welding, Laser), Solar Radiation

Introduction Polycarbonate

Selection of Optical Product Lines of Makrolon®



Mobility:

Makrolon® AX & AG



Makrolon® Ai



Makrolon® AL & LED



General Lighting:


Makrolon® LED5xxx



Makrolon® DQ




Makrolon® RW




Introduction Polycarbonate

Applications for volume diffusers for LED lighting



Volume Diffusers

How to avoid the bright spot of a LED?



Distribution of light over a wide angular range



Refraction

→ Surface structure (frosted glass, pyramids)

Scattering


→ Bulk diffuser, scattering by objects within the bulk

Combination of both is possible



Volume Diffusors

Optimizing the scattering power



Scattering power adjusted by:

- **Scattering agents:**
 - RI, Size, Structure
- **Concentration of scattering agent**
- **Thickness**




Volume Diffusors


Characterization of scattering power via HPA

Measurement of the HPA = Half Power Angle

- HPA is used to describe the scattering power on data sheet level.
- Measurement method is not standardized so far



Max. HPA = 60° (Ideal Scatter)



	1mm	2mm	3mm	4mm
HPA* =	9.4°	18.1°	26.6°	35.3°

* Typical value – no specification

Volume Diffusors


Generating optical material data for simulation



Radiative Transfer Equation for volume diffusors:

The **RTE** describes the redistribution of the radiance in a differential volume element due to absorption and scattering:

$$(\hat{s} \cdot \nabla)L(\vec{r}, \hat{s}) = -(\mu_a + \mu_s)L(\vec{r}, \hat{s}) + \underbrace{\mu_s \int_{4\pi} L(\vec{r}, \hat{s}')p(\hat{s}' \cdot \hat{s})d\Omega'}_{\text{In scattering}}$$



Material Parameter:

μ_a : Absorption Coefficient (1/mm) \rightarrow Absorption

μ_s : Scattering Coefficient (1/mm) \rightarrow Out scattering

$p(\hat{s}' \cdot \hat{s})$: Phase function \rightarrow Single particle scatter

We rely on commercial products.

Remark:

Clear transparent material:

$\mu_s = 0, p = 0 \rightarrow$ RTE leads to Lambert-Beer's Law

Determination the material parameter for volume diffusors


Model for phase functions



Henyey-Greenstein (HG 1941):

$$p_{HG}(\theta, g) = \frac{1}{4\pi} \frac{1 - g^2}{(1 + g^2 - 2g \cos \theta)^{\frac{3}{2}}}$$

g : Anisotropy factor ($-1 < g < 1$)




Gegenbauer (Reynolds-McCormick 1980):

$$p_{Geg}(\theta, g_{Geg}, \alpha) = \frac{\alpha g_{Geg} (1 - g_{Geg}^2)^{2\alpha}}{\pi [(1 + g_{Geg})^{2\alpha} - (1 - g_{Geg})^{2\alpha}] (1 + g_{Geg}^2 - 2g_{Geg} \cos \theta)^{(1+\alpha)}}$$

g_{Geg} : Anisotropy factor


$-1 < g_{Geg} < 1$ and $\alpha > -\frac{1}{2}$

$$(\alpha = \frac{1}{2} \rightarrow p_{Geg} = p_{HG})$$



Determination the material parameter for volume diffusors



Approach according to VDI/VDE 5596-3*



Determination the material parameter for volume diffusors



BTDF Measurement




Determination the material parameter for volume diffusors




Fit Results via Monte Carlo ray tracing (Gegenbauer-Model)


Weak scattering sample
1 mm




2 mm







3 mm







4 mm



Medium scattering sample



Strong scattering sample







Determination the material parameter for volume diffusors



Validation of the results of the fitting process

Validation via Luminance measurement:




Results

Comparison to luminance – LED CCT: 4000K




Sample thickness 2mm


Weak scattering sample




temperature = 4000 K, sample = schwach, thickness = 2 mm




Medium scattering sample




temperature = 4000 K, sample = mittel, thickness = 2 mm



Strong scattering sample



temperature = 4000 K, sample = stark, thickness = 2 mm



Summary

- **LED light often requires homogenization**
- **Volume diffusor can be tailor made for this application**
- **Simple characterization of volume diffusor is given by transmittance and HPA**
- **BTDF measurements are crucial to characterize volume diffusors**
- **For simulation we want provide validated optical material data**
- **With the aid of BTDF measurements and via parameter fitting we can evaluate the material data for volume diffusors to deliver input data for commercial software packages**



THANK YOU!

Dr. Rafael Oser

Covestro Deutschland AG – Group-Innovation

Rafael.Oser@Covestro.com



Forward-looking statements

This presentation may contain forward-looking statements based on current assumptions and forecasts made by Covestro AG.

Various known and unknown risks, uncertainties and other factors could lead to material differences between the actual future results, financial situation, development or performance of the company and the estimates given here. These factors include those discussed in Covestro's public reports, which are available on the Covestro website at www.covestro.com.

The company assumes no liability whatsoever to update these forward-looking statements or to adjust them to future events or developments.